


Operating instructions

**Laser Distance Sensor**

**PLDM1010(H)**  
**PLDM1030(H)**

E\_49012.pdf



2017-03  
31.03.2017  
tb

Revision Index:  
Revision date:  
Processed by:

Table of Contents

1	Introduction .....	4
1.1	Product identification .....	5
1.2	Components .....	5
1.3	Validity .....	5
2	Application examples .....	6
2.1	SerialinterfaceRS-232/RS-422 .....	6
2.2	Analog and digital output .....	6
2.3	External display .....	6
2.4	External trigger .....	6
2.5	SSIconnection .....	7
2.6	Positioning .....	7
3	Device overview and setup .....	8
3.1	Connection for configuration .....	8
3.2	Output interfaces .....	9
3.2.1	Output configuration example .....	9
3.3	Operation modes .....	10
3.3.1	Controlled mode .....	10
3.3.2	Stand-alone mode .....	11
3.4	Measuring characteristics .....	12
3.4.1	Measuring characteristics overview .....	12
3.4.2	Moving target characteristic .....	13
3.4.3	Error behavior .....	14
3.5	Special user commands .....	15
3.5.1	Offset / Gain .....	15
3.5.2	Output format .....	15
3.6	Output value filter .....	16
3.6.1	Moving average filter .....	16
3.6.2	Spikesuppressionfilter .....	16
3.6.3	Errorsuppressionfilter .....	16
4	Installation .....	17
4.1	Mounting .....	17
4.1.1	Mounting of the device .....	17
4.1.2	Mounting for the reflective plate .....	17
4.1.3	Alignment of the laser beam .....	17
4.1.4	LaserLifetimeconsideration .....	17
4.2	Device wiring .....	17
4.2.1	Power supply .....	17
4.2.2	Cable connection .....	17
4.2.3	Shield and ground .....	17
4.2.4	Serial connection .....	18
4.2.5	Analog/Digitalconnection .....	19
4.2.6	SSI connection .....	19
4.2.7	External trigger connection .....	20
5	Technicaldata .....	21
5.1	Measuring accuracy definition .....	21
5.2	Measuring performance influences .....	21
5.3	Prevention of erroneous measurements .....	22
5.3.1	Rough surfaces .....	22
5.3.2	Transparent surfaces .....	22
5.3.3	Wet, smooth, or high-gloss surfaces .....	22
5.3.4	Inclined, round surfaces .....	22
5.3.5	Multiple reflections .....	22
5.3.6	Influence of sun light .....	22
5.4	Specifications .....	23
6	Electrical components .....	24
6.1	DN switch .....	24
6.2	Reset switch .....	24
6.3	Digital output .....	24
6.4	Digital input .....	24
6.5	Analog output .....	25
6.6	RS-232 serial interfaces .....	25
6.7	RS-422 serial interface .....	25
6.8	SSI output .....	26
6.8.1	SSI Specification .....	26
6.8.2	SSI Timing .....	26
6.9	Connector .....	27
6.9.1	D-Sub connector .....	27
6.9.2	Screw terminal .....	27
7	Physical dimensions .....	28
8	Factory settings .....	28

8.1 Standard configuration.....	28
8.2 User configured measurement.....	28
9 Command set.....	29
9.1 General.....	29
9.1.1 Command termination <trm>.....	29
9.1.2 Device identification <i>N</i> .....	29
9.1.3 Parameter separator.....	29
9.1.4 Set/Get commands.....	29
9.1.5 Startup sequence.....	29
9.2 Operation commands.....	30
9.2.1 Distancemeasurement(sNg).....	30
9.2.2 Singlesensortracking(sMh).....	30
9.2.3 Single sensor tracking with timer(sMh).....	30
9.2.4 Tracking with buffering – Start (sM).....	31
9.2.5 Read out - Tracking with buffering(sNg).....	31
9.2.6 STOP/CLEAR command (sNc).....	31
9.2.7 Signalmeasurement (sNm).....	31
9.2.8 Temperature measurement (sMt).....	32
9.2.9 LaserON(sNo).....	32
9.2.10 Laser OFF (sNp).....	32
9.3 Configuration commands.....	33
9.3.1 Set communication parameter (sMbr).....	33
9.3.2 Measuring characteristic configuration (sNuc).....	34
9.3.3 Set auto start configuration (sNA).....	35
9.3.4 Set/Get analog output min level (sMwm).....	35
9.3.5 Set/Get analog output value in error case (sNve).....	35
9.3.6 Set/Get analog output distance range (sMv).....	36
9.3.7 Set/Get digital output levels (sNh).....	37
9.3.8 Configure digital input (sNDI1).....	38
9.3.9 Read digital input (sMRI).....	38
9.3.10 Interface 2 configuration (RS-422 / SSI).....	39
9.3.11 Set/Get error value on SSI output.....	40
9.3.12 Set/Get measurement filter configuration (sMfi).....	40
9.3.13 Save configuration parameters (sNs).....	40
9.3.14 Set configuration parameters to factory default (sMd).....	41
9.3.15 Get software version (sNsv).....	41
9.3.16 Get serial number (sNsn).....	41
9.3.17 Get device generation and type (dg).....	42
9.3.18 Get device type (dt).....	42
9.4 Special user operation commands.....	43
9.4.1 Userdistancemeasurement (sMug).....	43
9.4.2 Usersinglesensortracking (sMuh).....	43
9.4.3 User single sensor tracking with timer(sMuh).....	44
9.4.4 User tracking with buffering – Start (sMuf).....	44
9.4.5 Read out – User tracking with buffering (sMuq).....	44
9.5 Special User configuration commands.....	45
9.5.1 Set user auto start configuration (sNuA).....	45
9.5.2 Set/Get user distance offset (sMuof).....	45
9.5.3 Set/Get user distance gain (sMuga).....	45
9.5.4 User output protocol (sNuo).....	46
9.6 Error codes.....	47
10 Safety instructions.....	48
10.1 Use of the instrument.....	48
10.2 Limits to use.....	48
10.3 Areas of responsibility.....	49
10.4 Hazards in use.....	49
10.5 Laser classification.....	50
10.6 Electromagnetic compatibility (EMC).....	51
10.7 Producer Standards.....	51
10.8 Disposal.....	51
10.9 Labeling.....	51
10.10 Laser Specification.....	52
10.11 Maintenance.....	52

## I Introduction

The PLDM1010(H) and PLDM1030(H) are powerful distance-measuring instruments for integration into industrial applications. They allow accurate and contactless distance measurement over a wide range using the reflection of a laser beam:




Fig. 1 Standard application

### Key features

- Measurement range 0.05 to 500 m
- Serial interface (RS-232 and RS-422)
- Synchronous Serial Interface (SSI)
- Connection of up to 10 modules on a single RS-422 line
- Wide range power supply (9...30VDC), heating option (24...30VDC)
- Programmable analog output (0/4...20mA)
- Two programmable digital outputs (DOut/In1 and DOut2)
- Digital output for error signalization (DOutErr)
- One programmable digital input (DOut/In1)
- ASCII protocol to control external displays
- D-Sub connector and screw terminal joint for easy connection of PLDM1030(H)
- IP65 (protected against ingress of dust and water)
- 4 LEDs for status signaling
- Optional: Internal heater for device operation down to -40°C
- Laser class II (<0.95mW)
- Accessories for easy use of the sensor



**Use of controls or adjustments or performance of procedures other than those specified in this Technical Reference Manual may result in hazardous radiation exposure.**



## I.1 Product identification

The product is identified by the label on the top of the sensor:

**Measurement rate of up to 250 Hz and a maximum measuring distance of 500m**

	Typical Accuracy 1.0mm	Typical Accuracy 3.0mm
Standard version	PLDM1010 Part No.: 4902	PLDM1030 Part No.: 4901
Extended temperature range	PLDM1010H Part No.: 4902H	PLDM1030H Part No.: 4901H

## I.2 Components



- |   |   |
|---|---|
| <p><b>1 Status LEDs</b><br/>status signaling</p> <p><b>2 15-Pin D-Sub connector</b><br/>RS-422, RS-232, SSI, analog, digital output</p> <p><b>3 Cable gland (M16 x 1.5mm)</b><br/>for connection cable insertion</p> <p><b>4 Cover</b><br/>provides access to the screw terminal,<br/>Screwdriver-type is Torx T9</p> | <p><b>5 Reset switch</b><br/>resets the PLDM10... to default settings</p> <p><b>6 Screw terminal</b><br/>RS-422, RS-232, SSI, analog, digital output</p> <p><b>7 DN switch</b><br/>defines the <b>Device Number (DN)</b> for RS-422 operation</p> <p><b>8 Laser beam outlet</b></p> <p><b>9 Receiver optics</b></p> <p><b>10 Product label</b><br/>see 10.9 Labeling on page 52</p> |
|---|---|

## I.3 Validity

This manual is valid for PLDM1010(H) and PLDM1030(H) devices with the following software version:

Interface software version: **0500 or later**

Module software version: **0400 or later**

To get the software version use the command described in 9.3.15 *Get software version (sNsv)* on page 41

## 2 Application examples

Since the configuration of the PLDM1010(H) and PLDM1030(H) is very flexible the device is usable in various situations. The following application examples give an idea of possible applications. Please visit [www.fotoelektrik-pauly.de](http://www.fotoelektrik-pauly.de) for a detailed description of the mentioned application examples and check for additional application examples.

### 2.1 Serial interface RS-232/RS-422




Fig. 2: RS-422 connection to S7 PLC

While the RS-232 should be used for the configuration of the device (See 3.1 Connection for configuration on page 8) the RS-422 is made for communication in industrial environment (See 3.3.1 Controlled mode on page 10 and 4.2.4 Serial connection on page 18).

Fig. 2 shows the connection of multiple PLDM1010(H) or PLDM1030(H) devices to a Siemens S7 PLC.

For RS-422 connections use twisted pair cables only!

### 2.2 Analog and digital output




Fig. 3: AO Out DO/In1 and DO/Out2 connection

Activate the stand-alone mode (3.3.2 Stand-alone mode on page 11) and the device is ready to use. It starts measuring after power on and updates the analog and digital output according to the configuration. See 9.3.4 and the following chapters for the configuration commands.

### 2.3 External display




Fig. 4: External display connection

If Display Mode is enabled, the PLDM1010(H) or PLDM1030(H) formats the measured distance as ASCII string, which is understood by External Displays with a serial interface. Since the PLDM1010(H) or PLDM1030(H) transfers this formatted string automatically on the serial interface after completing a measurement. Measurement results can be displayed on an external display without an additional controller.

### 2.4 External trigger





Fig. 5: Use digital input as external trigger

The PLDM1010(H) and PLDM1030(H) includes the option of triggering measurements with an external switch or push button on Digital Input 1 (DO/In1). Using the Digital Input 1 disables the Digital Output 1.

Please refer to 3.3.2.2 Manual start configuration on page 11

## 2.5 SSI connection



Set the PLDM1010(H) or PLDM1030(H) in stand-alone mode (3.3.2 Stand-alone mode on page 11) and connect it to a SSI master as shown in Fig. 6. The measured distances are immediately available at the SSI output. See 9.3.10 Interface 2 configuration (RS- 422 / SSI) on page 39 for the detailed command description.

Never connect the SSI master before the PLDM1010(H) or PLDM1030(H) interface 2 is configured as SSI interface.

Fig. 6: SSI connection example

## 2.6 Positioning




Fig. 7: Positioning application

The figure on the left shows a typical positioning application. In this application the SSI interface of the PLDM1010(H) or PLDM1030(H) is directly connected to a position input of a motor drive. The drive controls the motor. In such a way, that the sledge moves to the position given as set point by the PLC.

The encoder is used for security reasons to double check the movement by the Drive.

In this applications the PLDM1010(H) or PLDM1030(H) uses the SSI interface (4.2.6 SSI connection on page 19) and the moving target characteristic (3.4.2 Moving target characteristic on page 13).


### 3 Device overview and setup

We recommend that you carry out the configuration steps in an office before mounting the device, especially if you are not familiar with the PLDM1010(H) or PLDM1030(H).

Configure the outputs first and second do the configuration of the operation mode. The following sections describe the configuration steps and give an example.

#### 3.1 Connection for configuration

To be able to configure the PLDM1010(H) or PLDM1030(H), it must be powered and connected to a PC. Figure 8 shows the necessary connections. On the PC, any terminal program can be used to communicate with the module.





### 3.2 Output interfaces

The PLDM10... contains different interfaces. Measurement results and errors are signaled at the outputs as described below.

<b>RS-232</b>	The RS-232 is meant for the configuration of the device, however measurement can also be taken using the RS-232 interface. Measurement results and/or error codes are sent corresponding to the command description. To use this interface host system is needed as described in 3.3.1 Controlled mode on page 10.
<b>RS-422</b>	The RS-422 operates like the RS-232, but it is an industrial interface and therefore not only usable for configuration but also for controlled measurement as described in 3.3.1 Controlled mode on page 10. The RS-422 cannot be used simultaneous with the SSI interface since it uses the same signal lines.
<b>SSI Output</b>	The SSI Interface is implemented. The SSI interface is updated after each successful measurement as well as after an error occurs. If the interface is activated, it is updated in all operation modes. Binary and Gray code as well as error signalization is supported. (See 4.2.6 SSI connection on page 19)
<b>Analog Output</b>	The analog output is updated in controlled and stand-alone mode. It is configurable and works with two ranges: - 0..20mA - 4..20mA
<b>Digital Outputs</b>	Three digital outputs are included in the PLDM1010(H) and PLDM1030(H). Two of them are programmable, while the third is used to signal an error state of the device. The digital outputs are updated in all operation modes.

#### 3.2.1 Output configuration example

After connecting the PLDM1010(H) or PLDM1030(H), the following steps are necessary to configure the output behavior.

No.	Action	Comment	Command
1	Set current output range	Defines the current output range from 0 to 20mA or from 4 to 20mA.  <i>Example for device 0:</i> Set current output range from 4mA to 20mA.	s0vm+1<trm> <sup>1)</sup>
2	Set distance range	Defines the minimum distance (D <sub>min</sub> ) and the maximum distance (D <sub>max</sub> ) for the current range of the analog output.  <i>Example for device 0:</i> Set distance range from 0m to 10m	s0v+00000000+00100000<trm> <sup>1)</sup>
3	Set analog output in case of an error	Sets the current that should be applied in case of an error.  <i>Example for device 0:</i> Set current to 0mA in case of an error.	s0ve+000<trm> <sup>1)</sup>
4	Configure digital output	Set the ON and OFF level for the digital outputs.  <i>Example for device 0:</i> DOut/In1: off=2000mm on=2005mm DOut2: off=4000mm on=4005mm	s01+00020000+00020050<trm> <sup>1)</sup> s02+00040000+00040050<trm> <sup>1)</sup>
5	Configure SSI Output	Activate SSI output (RS-422 is deactivated)  <i>Example for device 0:</i> Set SSI configuration Set output value in error case to 12345	s0SSI+1<trm> <sup>1)</sup> s0SSIE+12345<trm> <sup>1)</sup>
6	Save settings	The changed configuration must be saved to make it permanent.  <i>Example for device 0:</i> Save settings for device 0	s0s<trm> <sup>1)</sup>

1) Commands are described in 9 Command set on page 29

Note: If the serial line settings of the device have been lost, please reset the configuration to the factory settings (8 Factory settings on page 28) using the reset button (6.2 Reset switch on page 24). Please note that the DN switch must be reset manually.

### 3.3 Operation modes

The first decision to be taken is the type of operating mode that will be used to perform distance measurements. While the controlled mode provides maximum flexibility and accuracy, it is often not suitable for integration into existing drives, PLCs or analog environments. In such cases the Stand-alone mode might be preferred.

controlled mode	stand-alone mode	
	Auto start	Manual start
The measurement is controlled by a host with commands such as - sNg - sNh - sNuf	The measurement starts after power on. This must be configured with the command - sNA - sNuA	After configuring the DOut/In1 as input, the measurement can be triggered by an external signal. Use the following command - sNDI
See 9.2 Operation commands starting on page 30	See 9.3.3 Set auto start configuration (sNA) on page 35	See 9.3.8 Configure digital input (sNDI1) on page 38
After each measurement all outputs are updated corresponding to the configuration (See 9.3 Configuration commands on page 33).		

#### 3.3.1 Controlled mode

In controlled mode, each operation of a PLDM1010(H) or PLDM1030(H) is triggered by a command sent from a host system over a serial line. While a single device can be connected to the host system using the RS-232 interface, up to 10 devices can be connected to a single serial RS-422 line. The related command set is described in Chapter 9 on page 29.

##### 3.3.1.1 Configuration

After connecting the module, the steps below are necessary to configure the PLDM1010(H) or PLDM1030(H) for the controlled interface mode.

No.	Action	Comment	Command
1	Set DN switch	Changes to the Device Number (DN) are activated after a power cycle.  <i>Example for device 0:</i> Change the DN Switch to position 0	Set DN switch to position 0 Power OFF; Wait 10s; Power ON
2	Set controlled mode	Set the PLDM1010(H) or PLDM1030(H) to the controlled mode, if not already in controlled mode.  <i>Example for device 0:</i> Set to controlled mode by means of the stop command.	s0c<trm> <sup>1)</sup>
3	Set communication parameters	If necessary, change the settings for the serial interface.  <i>Example for device 0:</i> Set serial interface to 19200 Baud, 8 Bit, no Parity	s0br+2<trm> <sup>1)</sup> Power OFF; Wait 10s; Change settings on the host; Power ON

1) Commands are described in 9 Command set on page 29

Note: If the communication parameters of the device are lost, please reset the configuration to the factory settings ( 8 Factory settings on page 28) using the reset button (6.2 Reset switch on page 24). Please note that the DN switch must be reset manually.

##### 3.3.1.2 Host software

Host software is required for operation of the PLDM1010(H) or PLDM1030(H) in controlled mode. When connecting multiple devices to a single serial line (RS-422), strict Master-Slave communication must be implemented PLDM1010(H) or (PLDM1030(H) operates as slave).

Careful testing of the host software together with the devices prior to installation is strongly recommended.

### 3.3.2 Stand-alone mode

Before starting the stand-alone mode, output configuration must be done (See 3.2 Output interfaces on page 9)

#### 3.3.2.1 Auto start configuration

The following steps are necessary to configure the PLDM1010(H) or PLDM1030(H) for stand-alone mode with auto start.

No.	Action	Comment	Command
1	Set auto start	Set the PLDM1010(H) or PLDM1030(H) to the stand-alone mode with auto start and with the desired sample rate.  <i>Example for device 0:</i> Set sample rate to fastest possible speed.	s0A+0<trm> <sup>1)</sup>

1) Commands are described in 9 Command set on page 29

Note: If the serial line settings of the device have been lost, please reset the configuration to the factory settings (8 Factory settings on page 28) using the reset button (6.2 Reset switch on page 24). Please note that the DN switch must be reset manually.

#### 3.3.2.2 Manual start configuration

Configure the Digital Input (see 9.3.8 Configure digital input (sNDI1) on page 38) to activate the external trigger to start measurements.

No.	Action	Comment	Command
1	Activate digital input DOut/In1	Defines the action for a trigger event on DOut/In1. <i>Example for device 0:</i> Configure DOut/In1 to start and stop tracking. If DOut/In1 is high, distances are measured and the result is transferred to the output at all interfaces. If DOut/In1 goes to low, the measurement stops	s0DI1+3<trm> <sup>1)</sup>
2	Save settings	The changed configuration must be saved to make it permanent.  <i>Example for device 0:</i> Save settings for device 0	s0s<trm> <sup>1)</sup>

1) Commands are described in 9 Command set on page 29

Note: If the serial line settings of the device have been lost, please reset the configuration to the factory settings (8 Factory settings on page 28) using the reset button (6.2 Reset switch on page 24). Please note that the DN switch must be reset manually.

### 3.4 Measuring characteristics

Multiple measuring characteristics are available in the PLDM10... measuring devices to meet different requirements for various applications. With these measuring characteristics measuring rate and accuracy can be optimized for special requirements.

The measuring device at factory settings has an accuracy of  $\pm 1$  mm at  $2\sigma$  (PLDM1010(H)) or  $\pm 3$  mm at  $2\sigma$  (PLDM1030(H)). Measuring rate depends on environmental conditions such as target surface, distance, background light (e.g. sun light), etc., e.g. the chosen processing time mode. Good environmental conditions increase measuring rate (e.g. white target surface or orange reflective target plate and dark environment).

#### 3.4.1 Measuring characteristics overview

Measuring char.	Measuring rate	Typical accuracy @ $2\sigma$		Description	Available in PLDM1030(H)				
					Error behavior <sup>1)</sup>				
					User Commands <sup>2)</sup>		A	✓	
					Normal Commands <sup>2)</sup>				
PLDM10 10(H)	PLDM10 30(H)								
<b>Normal</b> (factory setting)	max. 10 Hz <sup>3)</sup>	$\pm 1$ mm	$\pm 3$ mm	Measuring range on natural surface: typical 65 m Configuration command: sNuc+0+0 <sup>4)</sup>	✓	✓	<b>A</b>	✓	
<b>Fast</b>	max. 20 Hz <sup>1)</sup>	$\pm 2$ mm	$\pm 6$ mm	Increased measuring rate up to 20 Hz. Configuration command: sNuc+0+1 <sup>4)</sup>	✓	✓	<b>A</b>	✓	
<b>Precise</b>	max. 6 Hz <sup>1)</sup>	$\sim \pm 0.8$ mm	$\sim \pm 2.4$ mm	Increased accuracy of $\pm 0.8$ mm Surveying applications, short range applications etc. Configuration command: sNuc+0+2 <sup>4)</sup>	✓	✓	<b>A</b>	✓	
<b>Natural surface</b>	max. 6Hz, can drop to 0.25Hz @ up to approx. 80m	$\sim \pm 5$ mm @ up to approx. 80m	$\sim \pm 15$ mm @ up to approx. 80m	Increased measuring range on natural surfaces: typical 80 meters Measuring against far away natural surfaces or bad reflective surfaces such as black synthetic granules, etc. Configuration command: sNuc+0+3 <sup>4)</sup>	✓	✓	<b>A</b>	✓	
<b>Timed</b>	user programmed $\leq 35$ Hz	variable	variable	The device does not check the signal condition to ensure the specified accuracy is reached, a measurement value is transferred to the output at a defined measuring rate. This mode serves for applications where the accuracy is not important but the reaction time is critical Configuration command: sNuc+1+1 <sup>4)</sup>	x	✓	<b>A</b>	✓	
<b>Moving Target</b>	250Hz, SSI can poll with up to 500Hz	$\pm 1$ mm	$\pm 3$ mm	The device measures to a continuously moving target and the distance changes without any jumps. This measurement characteristic supervises the max speed, checks for distance jumps and includes a special filter to eliminate errors occurring for only a very short time. Configuration command: sNuc+2+0 <sup>4)</sup> (with error freezing)	✓	✓	<b>B</b>	✓	

- 1) The behavior in case of an error depends on the configuration. See 3.4.3 Error behavior on page 14
- 2) Changed characteristics do not influence all commands
- 3) Good environmental conditions (e.g. white target surface or orange reflective target plate and dark environment).
- 4) For the description of the command see 9.3.2 Measuring characteristic configuration (sNuc) on Page 34

### 3.4.2 Moving target characteristic

For continuous movements of a target which typically appears in positioning applications like automatic warehouses there is a special measurement characteristic built into the PLDM1010(H) and PLDM1030 (H) called "Moving target" (See 2.6 Positioning on page 7 for a sample application)




Fig. 9: Condition for moving target characteristic

To operate the PLDM1010(H) or PLDM1030(H) in this measurement characteristic successfully, distance jumps must not occur. The laser beam must always hit the target.

This measurement characteristic combines a fast measurement rate with the unique accuracy of the PLDM1010(H) and PLDM1030(H). The measurement rate is fixed and does not change during operation.

For RS-232, RS-422, analog and digital outputs, the output rate is 250Hz. The SSI interface can return reliable measurement data at up to 500Hz read out rate corresponding to the clock received from the master.

When measuring to a stopped target, the resulting distance will stay at a single value, it does not occur any deviation of the distance. This is necessary if the sensor is used for positioning in closed looped applications.

An optimized error handling suppresses short errors, that may occur by a short break of the laser beam. In addition an over speed detector (>10m/s) detects improper situations, which results in an error. This ensures robust operation in positioning applications.

The behavior of the device in case of a severe error can be defined by the operator (See 3.4.3 Error behavior on page 14).

For a description of the configuration command see 9.3.2 Measuring characteristic configuration (sNuc) on page 34.

### 3.4.3 Error behavior

The device has different error behaviors depending on the measuring characteristics and on the start operation.

#### 3.4.3.1 A - Behavior


In case the device detects an error, this error is signaled at the outputs. On the serial and SSI output the error code will be visible depending on the configuration. The error will be visible at the output until the device performs a successful measurement and outputs the new distance value or the device will be reset by command (sNc) or by a power cycle.

#### 3.4.3.2 B – Behavior (in moving target characteristic)

This error behavior is only relevant when using the moving target measurement characteristic.

Configuration \ Situation	with error freezing sNuc+2+0 <sup>1)</sup>	without error freezing sNuc+2+1 <sup>1)</sup>
Temporary error	The temporary error is converted into a permanent error. This error must be reset as described below.	The temporary error disappears as soon as the error condition is cleared (a successful measurement is done).
Permanent error	The permanent error must be reset as described below.	The permanent error must be reset as described below.

The error reset function depending on the start condition. The following diagram shows the error reset for the different start configurations.



1) For the description of the command see 9.3.2 Measuring characteristic configuration (sNuc) on Page 34

### 3.5 Special user commands

The standard command set is extended by a special user command set, which makes it possible to change the output format and apply a offset and gain.



**User command configuration do not influence Analog, Digital and SSI outputs.**

#### 3.5.1 Offset / Gain

The user can set an individual user gain and offset to create user defined output values. The output value is calculated as follows.

$Value_{User} = (Distance + Offset_{User}) \cdot \frac{GainNum_{User}}{GainDen_{User}}$	See 9.5.2 Set/Get user distance offset (sNuof) and 9.5.3 Set/Get user distance gain (sNuga) on page 45
---	---

With the offset and gain the result of the user commands (See 9.4 Special user operation commands on page 43) are changed only. Analog, Digital and SSI output values are not affected.

#### 3.5.2 Output format

The PLDM1010(H) and PLDM1030(H) is able to format the output value on the serial interface (RS-232/RS-422) in order to fit it to an ASCII display. By the command `sNuO` the length of the output value can be defined as well as the position of the decimal point. This command in combination with a gain and offset allows the direct connection of an external display as described under 2.3 External display on page 6.

The command is described under 9.5.4 User output protocol (sNuo) on page 46

### 3.6 Output value filter


The PLDM1010(H) and PLDM1030(H) contains a filter for the measurement value, which can be activated and offers different configurations. This filter is available in the following Measuring characteristics (see 3.4 Measuring characteristics) on the PLDM1010(H) or PLDM1030(H):

- Normal
- Fast
- Precise
- Natural Surface
- Timed

The output value filter is made of a moving average, a spike suppression as well as an error suppression filter. These filters are all configurable to offer most possible flexibility for the adaption of the PLDM1010(H) or PLDM1030(H) device to various applications.

This filter is inactive for the moving target characteristic.


#### 3.6.1 Moving average filter



The moving average filter averages a specified number of measurements. Maximum 32 measurement values can be averaged. If a new measurement value is present, this value will be added to the filter values, while the last value will be removed. The sum of all measurement values divided by the size of the filter is transferred to all outputs.

Fig. 10 Moving average filter


#### 3.6.2 Spike suppression filter



The spike suppression eliminates pairs of min max values inside the filter values (Number of filter values can be defined). Always the smallest and largest values are removed from the average calculation.

Fig. 11: Spike suppression filter

#### 3.6.3 Error suppression filter



A maximum number of errors inside the filtered values can be suppressed. If the number of errors inside the filtered values is less as the specified value, no error is shown at the output

See 9.3.12 Set/Get measurement filter configuration (sNfi) on page 40

Fig. 12: Error suppression




## 4 Installation

### 4.1 Mounting

#### 4.1.1 Mounting of the device

Three M4 threaded holes in the bottom of the PLDM1010(H) and PLDM1030(H) make it easy to mount the device. Always obey all applicable safety regulations and never use the device outside the specifications stated under 5 Technical data on page 21.

#### 4.1.2 Mounting for the reflective plate



Measuring to the reflective plate may generate erroneous measurements, if the reflective plate is mounted exactly at an angle of 90° to the laser beam. Therefore mount the reflective plate like shown in figure 13.

Avoid direct sunlight on the reflective plate to increase measurement performance.

Fig. 13: Reflective Plate mounting

#### 4.1.3 Alignment of the laser beam

Alignment of the laser beam is often difficult when the target is far away, as the laser spot is not visible. An optional telescopic viewfinder and an alignment jig is available to simplify the alignment procedure. (See [www.fotoelektrik-pauly.de](http://www.fotoelektrik-pauly.de) for additional accessories and further details).

#### 4.1.4 Laser Lifetime consideration

Since the life time of the laser is limited, operate the device in a way, that the laser is switched on only when necessary. The laser life time stated under 5 Technical data on page 21 relates to the time while the laser is on.

## 4.2 Device wiring

### 4.2.1 Power supply


For trouble-free operation use a separate power supply for the PLDM1010(H) and PLDM1030(H).

PLDM1010 and PLDM1030:	9...30V, 0.5A DC
PLDM1010H and PLDM1030H:	24...30V, 2.5A DC

### 4.2.2 Cable connection

A ferrite core must be fitted to the connecting cable. Use a ferrite core with an impedance of 150 Ω to 260 Ω at 25MHz and 640 Ω to 730 Ω at 100MHz. For example you can use KCF-65 from KE Kitagawa.

### 4.2.3 Shield and ground



The PLDM1010(H) and PLDM1030(H) contains two electrically isolated grounds, the general ground (GND) and the analog ground (AGND). GND and AGND are connected to the housing by a RC element. Please see figure 19.

Fig. 14 Connection between shield and ground

### 4.2.4 Serial connection

This connection is mainly used for the controlled mode or to configure the device.

#### RS-232

Only point-to-point communication is possible when using the RS-232 interface.

**Never connect multiple PLDM1010(H)s or PLDM1030(H)s on a RS-232 serial line**




Fig. 15 Point-to-point connection with RS-232

#### RS-422

It is possible to connect multiple devices on a single RS-422 line. To ensure proper operation, strict Master-Slave communication must be applied. It is important, that the Master has full control of the communication and never initiates a new communication before termination of the previous communication (answer from the PLDM1030(H) or timeout).

For RS-422 connections, use shielded twisted pair cables only! For detailed information following the RS-422 guidelines.




Fig. 16: Connecting multiple devices with RS-422



**Ensure, that all PLDM1010(H) and PLDM1030(H)s are set to different device numbers.**



**The RS-422 interface cannot be used simultaneous with the SSI interface.**

### 4.2.5 Analog/Digitalconnection

This connection is mainly used with the stand-alone mode. The analog interface of the PLDM1010(H) and PLDM1030(H) is isolated from the rest of the device (See 4.2.3 Shield and ground on page 17). When using the analog interface, connect the analog ground (AGND). Make sure, that the total resistance in the analog path is lower than 500 Ω.




Fig. 17: Connection of an instrument and a PLC

### 4.2.6 SSI connection

Connect a SSI master according to the connection diagram in Fig. 18. It is compulsory to use a twisted pair cable. See 6.8 SSI output on page 26 and 6.8 SSI output on page 26 for additional information on the SSI interface.




Fig. 18: Connection of a SSI Master

### Typical cable length

The maximum transmission rate depends on the cable length as shown in the following table. For detailed cable specification use the SSI guidelines. The transmission rate must be specified at the SSI master.

Max. cable length (typical)	max. transmission rate (typical)
< 12.5 m	< 810 kBaud
< 25 m	< 750 kBaud
< 50 m	< 570 kBaud
< 100 m	< 360 kBaud
< 200 m	< 220 kBaud
< 400 m	< 120 kBaud
< 500 m	< 100 kBaud



**The RS-422 interface cannot be used simultaneous with the SSI interface.**

## 4.2.7 External trigger connection




Fig. 19: Connection for external triggering

The DOut/In1 (Digital Output 1) can also be used as digital input. For safety reasons, always use a resistor to protect the connection terminal. The function of digital input can be configured by the command sNDI1 (see 9.3.8 Configure digital input (sNDI1) on page 38)

## 5 Technical data


### 5.1 Measuring accuracy definition

The measuring accuracy corresponds to the ISO-recommendation ISO/R 1938-1971 with a statistical confidence level of 95.4% (i.e.  $\pm$  twice the standard deviation  $\sigma$ , refer to diagram on the right). The typical measuring accuracy relates to average conditions for measuring. It is  $\pm 1.0\text{mm}$  for the PLDM1010(H) and  $\pm 3.0\text{mm}$  for the PLDM1030(H) valid in the tracking mode.

Maximum deviation may occur under unfavorable conditions such as bright sunlight or when measuring to poorly reflecting or very rough surfaces. Measuring accuracy may deteriorate by approximately  $\pm 0.02\text{mm/m}$  for distances above 30m.

The PLDM1010(H) and PLDM1030(H) does not compensate changes of atmospheric environment. These changes can influence the accuracy if measuring long distances (>150m) under conditions very different from 20°C, 60% relative humidity and 953 mbar air pressure. The influences of the atmospheric environment are described in

B.Edlen: "The Refractive Index of Air, Metrologia 2", 71-80 (1966)



### 5.2 Measuring performance influences

The PLDM1010(H) and PLDM1030(H) is an optical instrument, whose operation is influenced by environmental conditions. Therefore, the measuring range achieved in use may vary. The following conditions may influence the measuring range:

Key	Factors increasing range	Factors reducing range
Target surface	Bright and reflective surfaces such as the target plates (See Accessories)	Matt and dark surfaces Green and blue surfaces
Airborne particles	Clean air	Dust, fog, heavy rainfall, heavy snowfall
Sunshine	Darkness	Bright sunshine on the target

The measurement range may be influenced by the configuration of the measurement characteristic. See 9.3.2 Measuring characteristic configuration (sNuc) on page 34.

The PLDM1010(H) and PLDM1030(H) does not compensate the influence of the atmospheric environment, which may be relevant when measuring long distances (e.g. > 150m). These effects are described in:

B.Edlen: "The Refractive Index of Air, Metrologia 2", 71-80 (1966)


### 5.3 Prevention of erroneous measurements

#### 5.3.1 Rough surfaces

On a rough surface (e.g. coarse plaster), measure against the center of the illuminated area. To avoid measuring to the bottom of gaps in the surface use a target plate (see accessories on [www.fotoelektrik-pauly.de](http://www.fotoelektrik-pauly.de) or board).

#### 5.3.2 Transparent surfaces

To avoid measuring errors, do not measure against transparent surfaces such as colorless liquids (such as water) or (dust-free) glass. In case of unfamiliar materials and liquids, always carry out a trial measurement.

 Erroneous measurements can occur when aiming through glass panes or if there are several objects in the line of sight.

#### 5.3.3 Wet, smooth, or high-gloss surfaces

- 1 Aiming at an “acute” angle deflects the laser beam. The PLDM1010(H) or PLDM1030(H) may receive a signal that is too weak (error message 255) or it may measure the distance targeted by the deflected laser beam.
- 2 If aiming at a right angle, the PLDM1010(H) or PLDM1030(H) may receive a signal that is too strong (error message 256).

#### 5.3.4 Inclined, round surfaces

Measurement is possible as long as there is enough target surface area for the laser spot. On irregular and round surfaces the arithmetic average of the illuminated surfaces will be measured.

#### 5.3.5 Multiple reflections

Erroneous measurements may occur if the laser beam is reflected by other objects than the target. Avoid any reflective object along the measurement path.

#### 5.3.6 Influence of sun light

Aiming directly to the sun or the sun is exactly behind the target could make it impossible to measure distances.

## 5.4 Specifications

Typical measuring accuracy for PLDM1010 / PLDM1010H <sup>1,3)</sup> PLDM1030 / PLDM1030H <sup>1,3)</sup>	± 1.0 mm @ 2 $\sigma$ <sup>1,3)</sup> ± 3.0 mm @ 2 $\sigma$ <sup>1,3)</sup>
Typical repeatability for PLDM1010 / PLDM1010H <sup>1)</sup> PLDM1030 / PLDM1030H <sup>1)</sup>	± 0.3 mm @ 2 $\sigma$ <sup>1)</sup> ± 0.5 mm @ 2 $\sigma$ <sup>1)</sup>
Accuracy of the analog output PLDM1010 / PLDM1010H <sup>1)</sup> PLDM1030 / PLDM1030H <sup>1)</sup>	(9.3.6 Set/Get analog output distance range (sNv) on page 36) 0.1% programmed span (12 Bit) 0.1% programmed span (12 Bit)
Smallest unit displayed	0.1 mm
Measuring range on natural surfaces	0.05 m to approx. 65 m (80m on natural surface characteristic <sup>3)</sup> )
Measuring range on orange (reflective) target plate	Approx. 0.5 m to 500 m
Measuring reference	from front edge (See 7 Physical dimensions)
Typical diameter of laser spot at target at a distance of <sup>5)</sup> (diffraction rings)	4mm @ 5m; 8mm @ 10m; 15mm @ 30m
Time for a measurement Single measurement: PLDM1030(H) <sup>3)</sup> Tracking: PLDM1030(H) <sup>3)</sup>	Typical: 0.3 s to 4 s <sup>3)</sup> Typical: 4 ms to 4 s <sup>3)</sup>
Max target speed while moving target characteristic is active	Typical: 10m/s up to 150m 7m/s up to 500m/s
Light source	Laser diode 620-690 nm (red)      Beam divergence: 0.16 x 0.6 mrad IEC 60825-1:2007; Class 2      Pulse duration: 0.45x10 <sup>-9</sup> s FDA 21CFR 1040.10 and 1040.11      Maximum radiant power: 0.95 mW
Laser Life Time	typical 50'000h @ 20°C (See 4.1.4 Laser Life time consideration on page 17)
ESD	IEC 61000-4-2
EMC	EN 61000-6-4 EN 61000-6-2
Power supply PLDM1010 / PLDM1030 PLDM1010H / PLDM1030H	9 ... 30V DC 0,6A 24 ... 30V DC 2.5A (Heating option)
Dimensions	150 x 80 x 55 mm
Temperature range during operation <sup>2)</sup> PLDM1010 / PLDM1030 PLDM1010H / PLDM1030H	-10 °C to +50 °C -40 °C to +50 °C
Temperature range during storage	-40 °C to +70 °C
Degree of Protection	IP65; IEC60529 (protected against ingress of dust and water)
Weight	PLDM1010 / PLDM1030: 690 g PLDM1010H / PLDM1030H: 720 g
Standard interface	1 serial asynchronous interface RS-232 1 serial asynchronous interface RS-422 1 SSI 1 programmable analog output 0/4 ... 20mA 2 programmable digital outputs 1 programmable digital input 1 digital output for error status

1) See 5.1 Measuring accuracy on page 21.

2) In case of permanent continuous measurement (tracking mode) the max. temperature is reduced to 45°C

3) Accuracy and measurement speed depend on configuration (See 9.3.2 Measuring characteristic configuration (sNuc) on page 34), e.g. the chosen processing time mode

4) By measuring on the orange reflecting target plate the accuracy may be reduced to ± 1.5 mm @ 2s

5) The spot-size can vary depending on production lot

## 6 Electrical components

To open the side cover, a Torx T9 screwdriver is needed.


### 6.1 DN switch

This switch is used to set the Device number DN and can be set from 0 to 9. The default setting is 0.

### 6.2 Reset switch

To reset the device to factory settings do the following:

- Change DN Switch to position 0
- Switch OFF the power for the device
- Press the reset button and keep it pressed
- Switch on the power for the device
- Keep the reset button pressed until all LEDs on the device are illuminated
- Release the reset button
- Switch the power OFF and wait 5 seconds
- Switch on the power and wait until the green power LED is on



### 6.3 Digital output




Fig. 20: Open drain output with external load

The PLDM1010(H) and PLDM1030(H) contain two digital outputs for level monitoring (DOOut/In1 and DOOut2) and one digital output for error signalization (DOOutErr). These outputs are open drain outputs as shown in figure 20 and can drive up to **200mA**. Maximum switching voltage is 30V DC. In the ON state, the FET transistor is electro conductive.

### 6.4 Digital input

The Digital Output (DOOut/In1) can be configured as a Digital Input (DIIn1). This is useful for triggering measurements by means of an external switch or push button. Please refer to chapter 4.2.7 External trigger connection on page 20.

- Low Level is:  $U_{DI1} < 2VDC$   
 High Level is:  $U_{DI1} > 9VDC$  and  $U_{DI1} < 30VDC$



## 6.5 Analog output

The analog output of the PLDM1010(H) and PLDM1030(H) is a current source (0..20mA or 4..20mA). It is capable of driving loads up to 500 Ω.

$$e_{Dist} = Accuracy_{Device} + \frac{(MaxDist_{Conf} - MinDist_{Conf}) * Accuracy_{AO}}{100}$$

$e_{Dist}$  Total error in mm  $MaxDist_{Conf}$  Configured max Distance in mm  
 $Accuracy_{Gerät}$  Device accuracy in mm  $MinDist_{Conf}$  Configured min Distance in mm  
 $Accuracy_{AO}$  Accuracy of the analog output in %

Example:	PLDM1030(H)
Device accuracy	±3 mm
Min. Distance	0 mm
Max. Distance	10'000 mm
Accuracy analog output FLS	±0.1%
Total error	$3mm + \frac{(10000-0) * 0.1}{100} = \pm 13mm$

 The stated errors include all possible errors as Temperature drift, linearity, surface color and measurement distance.

## 6.6 RS-232 serial interfaces

The RS-232 interface is used for device configuration. It is made to connect the sensor to a PC to do the configuration either by terminal program or by the UtilitySW (See 3.1 Connection for configuration on page 8).



**If the Moving Target measurement characteristic is active, a measurement speed of 250Hz is only possible if the baud rate is set to 115200. Lower baud rates reduce the measurement speed**

## 6.7 RS-422 serial interface

The RS-422 interface is made for industrial communication and therefore long cables (twisted pair) are supported. This interface is thought to use the PLDM1010(H) or PLDM1030(H) in controlled mode.



**The RS-422 interface cannot be used simultaneous with the SSI interface.**



**If the Moving Target measurement characteristic is active, a measurement speed of 250Hz is only possible if the baud rate is set to 115200. Lower baud rates reduce the measurement speed**

## 6.8 SSI output

### 6.8.1 SSI Specification

SSI parameters	Setting for PLDM1010(H) and PLDM1030(H)
Distance output values	0.. 16777215 1/10mm (max. 1.67km)
Measurement value coding	Binary or gray, MSB first
Transmission mode	Configurable, 23/24-bit measurement value, error bit, error code
Resolution	0.1mm
Read out rate	≤ 500Hz
SSI clock rate from controller	83KHz to 1MHz, depending of cable length.
Time lag between two data packets, pause time $t_p$	> 1ms
Monoflop time, $t_m$	25μs
Electrical levels, line driver	RS-422/485
Cable connection	Twisted pair, shielded

### 6.8.2 SSI Timing




Fig. 21: Timing diagram SSI


- $t_m$  Monoflop Time: Minimum time to detect the end of transmission. After  $t_m$ , the data line goes to idle state and the slave updating the internal value for the next transmission.
- $t_p$  Pause time: Pause time between two consecutive clock sequences of the master.

The SSI is initially in the idle mode, where the data and clock lines stay 1 HIGH and the slave keeps updating its internal value. The transmission mode is evoked when the master initiates a sequence by pulling the clock line to low. Once, the slave receives the resulting falling edge 2 at the clock signal line, it automatically stops updating its internal value. With the first rising edge 3 of the clock line, the MSB of the sensor's value is transmitted and with consequent rising edges, the data bits are sequentially transmitted. After the transmission of the complete data word 4 (e.g. LSB is transmitted) an additional last rising edge 5 of the clock sets the clock line to HIGH. The slave sets or leaves the data line to low and remains there for the time  $t_m$ , to recognize the transfer timeout. If a falling edge of the clock signal (data-output request) is received within the time  $t_m$ , the same data as before will be transmitted again (multiple transmission).

If there were no clock pulses within time  $t_m$ , the slave starts updating its internal value after setting the data line to HIGH (idle mode). This marks the end of a single transmission of a data word. Once the slave receives a clock signal at a time,  $t_p$  ( $\geq t_m$ ) the updated position value is frozen and the transmission of the new value begins as described earlier.


## 6.9 Connector

### 6.9.1 D-Sub connector




Pin	Designator	Description
1	Rx	RS-232 receive line
2	Tx	RS-232 send line
3	T-	RS-422 send line negative SSI data output negative (if configured for SSI)
4	T+	RS-422 send line positive SSI data output positive (if configured for SSI)
5	R-	RS-422 receive line negative SSI clock input negative (if configured for SSI)
6	R+	RS-422 receive line positive SSI clock input positive (if configured for SSI)
7	V+	DC Power
8	V+	+ 9V...+30V for PLDM1030 +24V...+30V for PLDM1030H (Heating option)
9	DOut1	Digital output 1 (Open Drain) or Digital input 1
10	DOut/In2	Digital output 2 (Open Drain)
11	DOutErr	Digital output for error signalization (Open Drain)
12	AGND	Analog ground
13	AOut	Analog output (0/4..20mA)
14	GND	Ground line
15	GND	Ground line

### 6.9.2 Screw terminal



Designator	Description
R+	RS-422 send line negative SSI clock input negative (if configured for SSI)
R-	RS-422 send line positive SSI clock input positive (if configured for SSI)
T+	RS-422 receive line negative SSI data output negative (if configured for SSI)
T-	RS-422 receive line positive SSI data output positive (if configured for SSI)
Tx	RS-232 Transmit line
Rx	RS-232 Receive line
AGND	Analog ground
AOut	Analog output (0/4..20mA)
DOutErr	Digital output for error signalization (Open Drain)
DOut2	Digital output 2 (Open Drain)
DOut/In1	Digital output 1 (Open Drain) or Digital input 1
GND	Ground line
V+	Power DC + 9V...+30V for PLDM1010 or PLDM1030 +24V...+30V for PLDM1010H or PLDM1030H (Heating option)

## 7 Physical dimensions



All dimensions in mm

## 8 Factory settings

### 8.1 Standard configuration

Operation Mode	Controlled
Serial Communication	Setting 7 Baud: 19200 Parity: Even Data bit: 7 Stop: 1
Analog outputs	Min output: 4mA Range: 0m Error output: 0mA min: 10m
SSI Output	Inactive (default is RS-422 active) Replacement value in case of an 0
Device DN	ID Number: 0
Digital output 1 (DOut1)	ON: 2m + 5mm = 2005mm OFF: 2m - 5mm = 1995mm
Digital output 2 (DOut2)	ON: 1m - 5mm = 995mm OFF: 1m + 5mm = 1005mm
Digital input 1 (DIn)	Inactive, configured as output

### 8.2 User configured measurement

User distance offset and gain	User distance offset = 0mm User Gain Num = Gain = $\frac{GainNum_{User} = 1000}{GainDen_{User} = 1000} = 1$ 1000 User Gain Den = 1000
Measurement characteristic	Normal
Measurement Filter	inactive
Output protocol	No special configuration, display distance

## 9 Command set

### 9.1 General

#### 9.1.1 Command termination <trm>

All commands for the PLDM1010(H) or PLDM1030(H) are ASCII based and terminated <trm> with <cr><lf>.

#### 9.1.2 Device identification *N*

Since the device can be addressed with the DN switch, the DN is represented in the commands by *N*. At the location of the *N* insert the Device Number (DN).

#### 9.1.3 Parameter separator

The command syntax uses the '+' sign as parameter separator. The '+' sign can be replaced by the minus '-' sign if applicable by the command.

#### 9.1.4 Set/Get commands

All configuration commands that are used to set configuration values can also be used to read the currently set value by omitting the parameter. The command syntax is described as follows:

	Set command	Get command
Command	s <i>N</i> uof+xxxxxxxx<trm>	s <i>N</i> uof<trm>
Return successful	g <i>N</i> uof?<trm>	g <i>N</i> uof+xxxxxxxx<trm>
Return error	g <i>N</i> @Ezzz<trm>	g <i>N</i> @Ezzz<trm>
Parameters	<i>N</i> Device Number (DN) xxxxxxxx Offset in 1/10 mm; + positive / - negative zzz Error code	

#### 9.1.5 Startup sequence

After power on, the PLDM1010(H) or PLDM1030(H) does all the initializations and sends a start sequence g*N*?. On this sequence, the *N* stands for the Device.Number (DN). After sending this start sequence, the PLDM1010(H) or PLDM1030(H) is ready to use.

## 9.2 Operation commands

### 9.2.1 Distance measurement (sNg)

Triggers simple measurement of distance. Each new command cancels an active measurement.

	Command	
Command	<code>sNg&lt;trm&gt;</code>	
Return successful	<code>gNg+xxxxxxxx&lt;trm&gt;</code>	
Return error	<code>gN@Ezzz&lt;trm&gt;</code>	
Parameters	<i>N</i> Device Number (DN) xxxxxxxx Distance in 1/10 mm zzz Error code	

### 9.2.2 Single sensor tracking (sNh)

Triggers continuous measurements of the distance. The measurements are made as fast as possible (Measurement speed depends on target conditions). This command is not to be used with more than one PLDM1010(H) or PLDM1030(H) on a RS-232/RS-422 line. The measurements are continued until the STOP/CLEAR command is issued. The status LEDs and the digital outputs are updated corresponding to the new measured distance.



**Never use this command if more than one module is connected to the RS-232/RS-422 line**

	Command	
Command	<code>sNh&lt;trm&gt;</code>	
Return successful	<code>gNh+xxxxxxxx&lt;trm&gt;</code>	
Return error	<code>gN@Ezzz&lt;trm&gt;</code>	
Parameters	<i>N</i> Device Number (DN) xxxxxxxx Distance in 0.1mm zzz Error code	

### 9.2.3 Single sensor tracking with timer (sNh)

This command does the same as the `sNf` command, but the unit sends the results directly to the output.



**Never use this command if more than one device is connected to the RS-422 line**

	Command	
Command	<code>sNh+xxx&lt;trm&gt;</code>	
Return successful	<code>gNh+yyyyyyyy&lt;trm&gt;</code>	
Return error	<code>gN@Ezzz&lt;trm&gt;</code>	
Parameters	<i>N</i> Device Number (DN) xxx Sampling time in 10ms (if 0 -> use max. possible sample rate) yyyyyyyy Distance in 0.1mm zzz Error code	

### 9.2.4 Tracking with buffering – Start (sNf)

Triggers continuous measurements of the distance with internal buffering in the device (buffer for one measurement). The rate of measurements is defined with the sampling time. If the sampling time is set to zero, the measurements are executed as fast as possible (Measuring speed depends on target conditions). The last measurement can be read out from the module with the command `sNq`. The measurements are continued until the 'sNc' command is issued.

	Set command	Get command
Command	<code>sNf+xxxxxxxx&lt;trm&gt;</code>	<code>sNf&lt;trm&gt;</code>
Return successful	<code>gNf?&lt;trm&gt;</code>	<code>gNf+xxxxxxxx&lt;trm&gt;</code>
Return error	<code>gN@Ezzz&lt;trm&gt;</code>	<code>gN@Ezzz&lt;trm&gt;</code>
Parameters	N Device Number (DN) xxxxxxx Sampling time in 10ms (if 0 -> max possible rate) zzz Error code	

### 9.2.5 Read out - Tracking with buffering(sNq)

After starting "tracking with buffering" with the command `sNf`, the latest measurement can be read out from the module with the command `sNq`. This command does not work if the tracking with buffering is not started.

	Command	
Command	<code>sNq&lt;trm&gt;</code>	
Return successful	<code>gNq+xxxxxxxx+c&lt;trm&gt;</code>	
Return error	<code>gN@Ezzz+c&lt;trm&gt;</code>	
Parameters	N Device Number (DN) xxxxxxx Distance in 0.1mm c 0 = no new measurement since last sNq command 1 = one new measurement since last sNq command, not overwritten 2 = more than one measurement since last sNq command, overwritten zzz Error code	

### 9.2.6 STOP/CLEAR command (sNc)

Stops the current execution and resets the status LEDs as well as the digital outputs.

	Command	
Command	<code>sNc&lt;trm&gt;</code>	
Return successful	<code>gN?&lt;trm&gt;</code>	
Return error	<code>gN@Ezzz&lt;trm&gt;</code>	
Parameters	N Device Number (DN) zzz Error code	

### 9.2.7 Signal measurement (sNm)

Signal measurement can be done continuously or with a single measurement. The signal strength is returned as a relative number in the typical range of 0 to 40 millions.

The value for the signal strength is just an approximate value, it differs from device to device and also depends on environment conditions.

	Command	
Command	<code>sNm+c&lt;trm&gt;</code>	
Return successful	<code>gNm+xxxxxxxx&lt;trm&gt;</code>	
Return error	<code>gN@Ezzz&lt;trm&gt;</code>	
Parameters	N Device Number (DN) c 0: single measurement 1: repetitive measurements ! warning: use with one sensor only xxxxxxx Signal strength (range 0.. 40 millions) zzz Error code	

### 9.2.8 Temperature measurement (sMt)

Triggers measurement of the temperature inside the sensor.

	Command	
Command	sMt<trm>	
Return successful	gMt+xxxxxxxx<trm>	
Return error	gMtEzzz<trm>	
Parameters	<i>N</i>	Device Number (DN)
	xxxxxxxx	Temperature in 0.1°C
	zzz	Error code

### 9.2.9 Laser ON (sNo)

Switches the laser beam ON for easy adjustment.

	Command	
Command	sNo<trm>	
Return successful	gN?<trm>	
Return error	gNtEzzz<trm>	
Parameters	<i>N</i>	Device Number (DN)
	zzz	Error code

### 9.2.10 Laser OFF (sNp)

Switches the laser OFF.

	Command	
Command	sNp<trm>	
Return successful	gN?<trm>	
Return error	gNtEzzz<trm>	
Parameters	<i>N</i>	Device Number (DN)
	zzz	Error code



## 9.3 Configuration commands

### 9.3.1 Set communication parameter (sMbr)

Sets the communication parameters for the serial interface.



**This command saves all configuration parameters to Flash. The changed baud rate is activated after the next power on.**

**Bold** = default parameters (first use or after reset)

	Command																																																									
Command	sNbr+yy<trm>																																																									
Return successful	gN?<trm>																																																									
Return error	gN@Ezzz<trm>																																																									
Parameters	<p><i>N</i> Device Number (DN)  <i>yy</i> Defines the new settings</p> <table border="1"> <thead> <tr> <th>yy</th> <th>Baud rate</th> <th>Data bits</th> <th>Parity</th> <th>yy</th> <th>Baud Rate</th> <th>Data bit</th> <th>Parity</th> </tr> </thead> <tbody> <tr> <td>00</td> <td>1200</td> <td>8</td> <td>N</td> <td>06</td> <td>9600</td> <td>7</td> <td>E</td> </tr> <tr> <td>01</td> <td>9600</td> <td>8</td> <td>N</td> <td><b>07</b></td> <td><b>19200</b></td> <td><b>7</b></td> <td><b>E</b></td> </tr> <tr> <td>02</td> <td>19200</td> <td>8</td> <td>N</td> <td>08</td> <td>38400</td> <td>8</td> <td>N</td> </tr> <tr> <td>03</td> <td>1200</td> <td>7</td> <td>E</td> <td>09</td> <td>38400</td> <td>7</td> <td>E</td> </tr> <tr> <td>04</td> <td>2400</td> <td>7</td> <td>E</td> <td>10</td> <td>115200</td> <td>8</td> <td>N</td> </tr> <tr> <td>05</td> <td>4800</td> <td>7</td> <td>E</td> <td>11</td> <td>115200</td> <td>7</td> <td>E</td> </tr> </tbody> </table>		yy	Baud rate	Data bits	Parity	yy	Baud Rate	Data bit	Parity	00	1200	8	N	06	9600	7	E	01	9600	8	N	<b>07</b>	<b>19200</b>	<b>7</b>	<b>E</b>	02	19200	8	N	08	38400	8	N	03	1200	7	E	09	38400	7	E	04	2400	7	E	10	115200	8	N	05	4800	7	E	11	115200	7	E
yy	Baud rate	Data bits	Parity	yy	Baud Rate	Data bit	Parity																																																			
00	1200	8	N	06	9600	7	E																																																			
01	9600	8	N	<b>07</b>	<b>19200</b>	<b>7</b>	<b>E</b>																																																			
02	19200	8	N	08	38400	8	N																																																			
03	1200	7	E	09	38400	7	E																																																			
04	2400	7	E	10	115200	8	N																																																			
05	4800	7	E	11	115200	7	E																																																			

### 9.3.2 Measuring characteristic configuration (sNuc)

Multiple measuring characteristic available in the PLDM1010(H) or PLDM1030(H) measuring devices meet different requirements for various applications. With these measuring characteristics measuring rate and accuracy can be optimized for special requirements.

While on factory settings, the PLDM1010(H) measuring device has an accuracy of  $\pm 1 \text{ mm } 2\sigma$  and the PLDM1030(H) measuring device has an accuracy of  $\pm 3 \text{ mm } 2\sigma$ .

Measuring rate depends on environmental conditions such as target surface, distance, background light (e.g. sun light), etc. Good environmental conditions increase measuring rate (e.g. white target surface or orange reflective target plate and dark environment).

For a detailed description of the different measuring characteristics see 3.4 Measuring characteristics on page 12.



**The configuration command sNuc is applied to the special user commands and to the standard commands.**

	Set command	Get command
Command	sNuc+a+b<trm>	sNuc
Return successful	gNuc+xxxxxxxx+yyyyyyyy<trm>	gNuc+xxxxxxxx+yyyyyyyy<trm>
Return error	gN@Ezzz<trm>	gN@Ezzz<trm>
Parameters	<p><i>N</i> Device (DN)</p> <p><i>a</i> = 0 <i>b</i> = 0: Normal 1: Fast 2: Precise 3: Natural surface</p> <p><i>a</i> = 1 <i>b</i> = 1: Timed</p> <p><i>a</i> = 2 <i>b</i> = 0: Moving target characteristic <b>with</b> error freezing Every error will be preserved. For an error reset, the measurement must be restarted according to the configured operation mode. (See 3.4.3 Error behavior on page 14)</p> <p>1: Moving target characteristic <b>without</b> error freezing Distance jumps or unfavorable signal conditions may cause a temporary or permanent error. <i>Temporary error</i> As soon as the PLDM1010(H) or PLDM1030(H) is able to determine a new distance value, the error will disappear and the output will show the new distance value. The shortest possible time to display an error is 4..5ms. <i>Permanent error</i> The PLDM1010(H) and PLDM1030(H) is not able to determine a distance anymore. The error will be shown with an output rate of up to 250Hz. For an error reset, the measurement must be restarted according to the configured operation mode. (See 3.4.3 Error behavior on page 14)</p> <p><i>zzz</i> Error code</p>	

Configuration parameters need to be saved (See 9.3.13 Save configuration parameters (sNs) on page 40)

### 9.3.3 Set auto start configuration (sNA)

This command activates the stand-alone mode with auto start of the PLDM1010(H) or PLDM1030(H). It triggers continuous measurements of the distance. The analog, digital and SSI outputs are updated according to the measured distance values. The sampling time defines the measurement rate. If the sampling time is set to zero, the measurements are executed as fast as possible (depending on target conditions). The stand-alone mode with auto start is active until the STOP/CLEAR command (sNC) is received by the device.



The operating mode is stored in the PLDM1010(H) or PLDM1030(H) and activated immediately. This mode is also activated after next power ON.



Internally, “tracking with buffering” is started (command sNE). Therefore, the latest measurement can also be read out from the module with the command sNq.

	Command	
Command	sNA+xxxxxxx<trm>	
Return successful	gNA?<trm>	
Return error	gN@Ezzz<trm>	
Parameters	N Device Number (DN) xxxxxxx Sampling time in 10 ms (if 0 -> max. possible rate) zzz Error code	

### 9.3.4 Set/Get analog output min level (sNm)

This command sets the minimum analog output current level (0 or 4 mA).

	Set command	Get command
Command	sNm+x<trm>	sNm<trm>
Return successful	gNm?<trm>	gNm+x<trm>
Return error	gN@Ezzz<trm>	gN@Ezzz<trm>
Parameters	N Device Number (DN) x Minimum output for analog out 0: Minimum current is 0 mA 1: Minimum current is 4 mA zzz Error code	

Configuration parameters need to be saved (See 9.3.13 Save configuration parameters (sNs) on page 40)

### 9.3.5 Set/Get analog output value in error case (sNve)

This command sets the analog output current level in mA in case of an error. This level can be lower than the minimum level set in 9.3.4 Set/Get analog output min level (sNm).

	Set command	Get command
Command	sNve+xxx<trm>	sNve<trm>
Return successful	gNve?<trm>	sNve+xxx<<trm>
Return error	gN@Ezzz<trm>	gN@Ezzz<trm>
Parameters	N Device Number (DN) xxx Value in case of an error in 0.1mA If the value is set to 999, in case of an error keep the last valid distance zzz Error code	

Configuration parameters need to be saved (See 9.3.13 Save configuration parameters (sNs) on page 40)

### 9.3.6 Set/Get analog output distance range (sNv)

Sets the minimum and maximum distances corresponding to the minimum and maximum analog output current levels.

0...20mA

4...20mA

$$A_{out} = \frac{DIST - D_{min}}{D_{max} - D_{min}} * 20mA$$

$$A_{out} = \frac{DIST - D_{min}}{D_{max} - D_{min}} * 16mA + 4mA$$

*A<sub>out</sub>* Analog current output  
*DIST* Actual measured distance  
*D<sub>min</sub>* Distance programmed for the minimum output current  
*D<sub>max</sub>* Distance programmed for the maximum output current


	Set command	Get command
Command	sNv+xxxxxxxx+yyyyyyyy<trm>	sNv<trm>
Return successful	gNv?<trm>	gNv+xxxxxxxx+yyyyyyyy<trm>
Return error	gN@Ezzz<trm>	gN@Ezzz<trm>
Parameters	<i>N</i> Device Number (DN) xxxxxxxx Minimum distance in 1/10 mm corresponding to 0mA / 4mA yyyyyyyy Maximum distance in 1/10 mm corresponding to 20mA zzz Error code	

Configuration parameters need to be saved (See 9.3.13 Save configuration parameters (sNs) on page 40)

### 9.3.7 Set/Get digital output levels (sNn)


Sets the distance levels at which the digital outputs are switched ON and OFF with a hysteresis. Two different situations are possible:

#### ON level > OFF level



The ON level of the hysteresis is larger than the OFF level. With an increasing distance, the digital output is switched on (open drain output is closed) when the distance exceeds the ON level. With a decreasing distance, the digital output is switched off (open drain output is open) when the distance falls below the OFF level.

#### ON level < OFF level



The ON level of the hysteresis is smaller than the OFF level. With a decreasing distance, the digital output is switched on (open drain output is closed) when the distance falls below the ON level. With an increasing distance, the digital output is switched off (open drain output is open) when the distance exceeds the OFF level.

	Set command	Get command
Command	<code>sNn+xxxxxxxx+yyyyyyyy&lt;trm&gt;</code>	<code>sNn&lt;trm&gt;</code>
Return successful	<code>gNn?&lt;trm&gt;</code>	<code>gNn+xxxxxxxx+yyyyyyyy&lt;trm&gt;</code>
Return error	<code>gN@Ezzz&lt;trm&gt;</code>	<code>gN@Ezzz&lt;trm&gt;</code>
Parameters	<i>N</i> Device Number (DN) <i>n</i> Digital output port (1 or 2) <i>xxxxxxxx</i> Distance ON level in 1/10 mm for switching digital output ON <i>yyyyyyyy</i> Distance OFF level in 1/10 mm for switching digital output OFF <i>zzz</i> Error code	

Configuration parameters need to be saved (See 9.3.13 Save configuration parameters (sNs) on page 40)

### 9.3.8 Configure digital input (sNDI1)

The digital output 1 of the PLDM1010(H) or PLDM1030(H) can also be used as digital input. The command `sNDI1` configures an action for the device. The state of the digital input can be read with the command `sNRI`.



**On active digital input, the digital output function of DOut1 is deactivated**

	Set command	Get command
Command	<code>sNDI1+xxxxxxxx&lt;trm&gt;</code>	<code>sNDI1&lt;trm&gt;</code>
Return successful	<code>gNDI1?&lt;trm&gt;</code>	<code>sNDI1+xxxxxxxx&lt;trm&gt;</code>
Return error	<code>gN@Ezzz&lt;trm&gt;</code>	<code>gN@Ezzz&lt;trm&gt;</code>
Parameters	<p><i>N</i> Device Number (DN)</p> <p><i>xxxxxxxx</i> 0: Digital input inactive (DOut/In1 active)                      1: activate the digital input to read out its state with the command <i>9.3.9 Read digital input (sNRI)</i>.                      2: Trigger Distance measurement (sNg)                      3: Start/Stop Single sensor Tracking (sNh)                      4: Start/Stop Tracking with buffering (sNf)                      5: Trigger User Distance measurement (sNug)                      6: Start/Stop Single sensor User Tracking (sNuh)                      7: Start/Stop User Tracking with buffering (sNuf)                      8: Start/Stop Single sensor Timed Tracking (sNh+)<sup>1)</sup>                      9: Start/Stop Single sensor User Timed Tracking (sNuh+)<sup>1)</sup></p> <p><i>zzz</i> Error code</p>	

1) Uses time for the tracking as set by a previous `sNh+` or `sNuh+` command

**Configuration parameters need to be saved (See 9.3.13 Save configuration parameters (sNs) on page 40)**

### 9.3.9 Read digital input (sNRI)

Displays the state of the digital input, if the input is not inactive. (Necessary configuration of the digital input: `sNDI1+1`)

	Command	
Command	<code>sNRI&lt;trm&gt;</code>	
Return successful	<code>gNRI+x&lt;trm&gt;</code>	
Return error	<code>gN@Ezzz&lt;trm&gt;</code>	
Parameters	<p><i>N</i> Device Number (DN)</p> <p><i>x</i> 0: Input Off (Signal Low)                      1: Input On (Signal High)</p> <p><i>zzz</i> Error code</p>	

### 9.3.10 Interface 2 configuration (RS-422 / SSI)

The SSI interface is implemented on the PLDM1010(H) or PLDM1030(H) device only and deactivated by default. Since the SSI interface uses the same connection as the RS-422 interface only one of these two interface can be used at the same time.



**Use the stand-alone mode with auto start to automatically update the SSI output value. (9.3.3 Set auto start configuration (sNA) page 35)**

Connect the device by RS-232 to do the configuration and use the following commands to activate the SSI interface. See also 4.2.6 SSI connection on page 19 and 6.8 SSI output on page 26.

	Set command	Get command
Command	sNSSI+xxx<trm>	sNSSI<trm>
Return successful	gNSSI?<trm>	gNSSI+xxx<trm>
Return error	gN@Ezzz<trm>	gN@Ezzz<trm>
Parameters	<p><i>N</i> Device DN  <i>xxx</i> binary coded:                      Bit0 0: Interface 2 (IF2) functions as RS-422 (SSI is deactivated)                      1: Interface 2 (IF2) functions as SSI (RS-422 is deactivated)                      Bit1 0: Binary coded data output                      1: Gray coded data output                      Bit2 0: no error bit output                      1: error bit attached to the output data value                      Bit3 0: no additional error code output                      1: attach 8bit error code (Code -200)                      Bit4 0: 24 bit data value                      1: 23 bit data value  <i>zzz</i> Error code</p>	

Configuration parameters need to be saved (See 9.3.13 Save configuration parameters (sNs) on page 40)

#### 9.3.10.1 Configuration examples

##### 24 Bit data, Error code and Error bit

Data (24 Bit binary)														Error code (binary)								Er	ror bit												
MSB	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	MSB	7	6	5	4	3	2	1	0	LSB	0

<b>Configuration:</b>	01101 → 13
Bit0 = 1:	Interface 2 (IF2) functions as SSI (RS-422 is deactivated)
Bit1 = 0:	Binary coded data output
Bit2 = 1:	Error bit attached to the output data value
Bit3 = 1:	Attach 8 bit error code (Code -200)
Bit4 = 0:	24 bit data value
<b>Command:</b>	sNSSI+13

##### 23 Bit data and Error bit

Data (23 Bit gray)														Error bit											
MSB	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	LSB	0

<b>Configuration:</b>	10111 → 23
Bit0 = 1:	Interface 2 (IF2) functions as SSI (RS-422 is deactivated)
Bit1 = 1:	Gray coded data output
Bit2 = 1:	Error bit attached to the output data value
Bit3 = 0:	No additional error code output
Bit4 = 1:	23 bit data value
<b>Command:</b>	sNSSI+23

##### 24 Bit data

Data (24 Bit binary)																										
MSB	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	LSB	0

<b>Configuration:</b>	00001 → 1
Bit0 = 1:	Interface 2 (IF2) functions as SSI (RS-422 is deactivated)
Bit1 = 0:	Binary coded data output
Bit2 = 0:	No error bit output
Bit3 = 0:	No additional error code output
Bit4 = 0:	24 bit data value
<b>Command:</b>	sNSSI+1

### 9.3.11 Set/Get error value on SSI output

In case of an error the SSI output will show a value corresponding to this configuration. There can be a replacement value in a range of 0 to 16777215 (24Bit) or 0 to 8388607 (23Bit), the last valid distance value or the error code.

All values are shown either as binary value or gray coded depending on configuration.

	Set command	Get command
Command	sNSSIe+xxxxxxx<trm>	sNSSIe<trm>
Return successful	gNSSIe?<trm>	gNSSIe+xxxxxxx<trm>
Return error	gN@Ezzz<trm>	gN@Ezzz<trm>
Parameters	<i>N</i> Device Number (DN) xxxxxxxx 0..2 <sup>24</sup> -1 / 0..2 <sup>23</sup> -1: -1: -2: zzz Error code	Replacement value In case of an error, the data value will be replaced by this replacement value. (depending on the settings, the value will be converted to gray code): in case of an error the last distance value will stay at the output. in case of an error the error code will be at the output (converted to gray code if configured)

Configuration parameters need to be saved (See 9.3.13 Save configuration parameters (sNs) on page 40)

### 9.3.12 Set/Get measurement filter configuration (sNfi)

The filter applied to the measurement value can be configured according the following command

	Set command	Get command
Command	sNfi+aa+bb+cc<trm>	sNfi<trm>
Return successful	gNfi?<trm>	gNfi+aa+bb+cc<trm>
Return error	gN@Ezzz<trm>	gN@Ezzz<trm>
Parameters	<i>N</i> Device Number (DN) aa Filter length (0: Filter off, 32: max value) bb Number of spikes to suppress (always pairs of min and max value) cc max number of errors to suppress. Condition: 2*bb+cc <= 0.4*aa zzz Error code	

See 3.6 Output value filter on page 16 for additional information.

### 9.3.13 Save configuration parameters (sNs)

This command saves all configuration parameters, which are set by the commands above. The parameters are written to the Flash Memory.

	Command	
Command	sNs<trm>	
Return successful	gNs?<trm>	
Return error	gN@Ezzz<trm>	
Parameters	<i>N</i> Device Number (DN) zzz Error code	



### 9.3.14 Set configuration parameters to factory default (sNd)

This command restores all configuration parameters to their factory default values. The parameters are written to the Flash Memory and therefore permanently saved.



**The communication parameters are also reset to factory settings.**

	Command	
Command	sNd<trm>	
Return successful	gN?<trm>	
Return error	gN@Ezzz<trm>	
Parameters	N	Device Number (DN)
	zzz	Error code

### 9.3.15 Get software version (sNsv)

Retrieves the software version of the PLDM1010(H) or PLDM1030(H).

	Command	
Command	sNsv<trm>	
Return successful	gNsv+xxxxyyy<trm>	
Return error	gN@Ezzz<trm>	
Parameters	N	Device Number (DN)
	xxxx	Internal measuring module software version number
	yyyy	Interface software version
	zzz	Error code

### 9.3.16 Get serial number (sNsn)

Retrieves the serial number of the PLDM1010(H) or PLDM1030(H).

	Command	
Command	sNsn<trm>	
Return successful	gNsn+xxxxxxxx<trm>	
Return error	gN@Ezzz<trm>	
Parameters	N	Device Number (DN)
	xxxxxxxx	Serial number of the device
	zzz	Error code

### 9.3.17 Get device generation and type (dg)

This command returns the device type, generation and current communication settings. Works only from device generation C on.



**Never use this command if more than one device is connected to the RS-422 line**

Command	
Command	dg
Return successful	<i>gNdg+xxx+yz?&lt;trm&gt;</i>
Return error	<i>gN@Ezzz</i>
Parameters	<i>N</i> Device Number (DN) <i>x</i> Bit coded number to identify the device: 0x53 (83) PLDM1010(H) or PLDM1030 <i>y</i> (additional internal information) <i>z</i> Communication settings (see command sNbr+C) <i>zzz</i> Error code

### 9.3.18 Get device type (dt)

This command returns the device type.



**Never use this command if more than one device is connected to the RS-422 line**

Command	
Command	dt
Return successful	<i>gNdt+xyy&lt;trm&gt;</i>
Return error	<i>gN@Ezzz</i>
Parameters	<i>N</i> Device Number (DN) <i>x</i> Generation shown as a number. <i>yy</i> Device number. Output for <i>xyy</i> 302: PLDM1010(H) or PLDM1030(H) <i>zzz</i> Error code

## 9.4 Special user operation commands

The special user commands are user configurable and are an extension to the standard commands. Use these commands carefully and only if you really understand their impact.

The syntax of the user commands differ to the standard commands as follows:

Standard Commands:        sNx  
 User Commands:            sNuxx

The user configuration parameters influence the result of the user commands. A gain and offset may be applied to the measurement result and the output format may be configured.

### 9.4.1 User distance measurement (sNug)

Triggers simple distance measurement, similar to the command 9.2.1 Distance measurement (sNg) on page 30. This command returns the distance corrected with the user offset and user gain as set with the commands 9.5.2 Set/Get user distance offset (sNuof) and 9.5.3 Set/Get user distance gain (sNuga) on page 45.



**This command takes the user distance offset and user gain into account**

	Command	
Command	sNug<trm>	
Return successful	gNug+xxxxxxxx<trm>	
Return error	gN@Ezzz<trm>	
Parameters	N            Device Number (DN) xxxxxxxx   Distance in 0.1mm zzz         Error code	

### 9.4.2 User single sensor tracking (sNuh)

Triggers continuous measurement of the distance and outputs the result immediately to the serial interface. The distance measurement is executed as fast as possible (depending on target conditions). The measured distance is corrected with the user offset and user gain as set with the commands 9.5.2 Set/Get user distance offset (sNuof) and 9.5.3 Set/Get user distance gain (sNuga) on page 45. The measurements are continued until the STOP/CLEAR command (sNc) is received by the device.



**This command takes the user distance offset into account**



**Never use these commands if more than one device is connected to the RS-422 line**

	Command	
Command	sNuh<trm>	
Return successful	gNuh+xxxxxxxx<trm>	
Return error	gN@Ezzz<trm>	
Parameters	N            Device Number (DN) xxxxxxxx   Distance in 0.1mm zzz         Error code	

### 9.4.3 User single sensor tracking with timer(sNuh)

This command does the same as the sNuf command, but the unit sends the results directly to the output.



**This command takes the user distance offset and user gain into account**



**Never use this command if more than one device is connected to the RS-422 line**

	Command	
Command	sNuh+xxx<trm>	
Return successful	gNuh+yyyyyyyyy<trm>	
Return error	gN@Ezzz<trm>	
Parameters	N Device Number (DN) xxx Sampling time in 10ms (if 0 -> use max. possible sample rate) yyyyyyyyy Distance in 0.1mm zzz Error code	

### 9.4.4 User tracking with buffering – Start (sNuf)

Triggers continuous measurement of the distance with internal buffering in the device (buffer for one measurement). The measured distance is corrected with the user offset and user gain as set with the command 9.5.2 Set/Get user distance offset (sNuof) and 9.5.3 Set/Get user distance gain (sNuga) on page 45. Define the rate of measurements with the sampling time. If the sampling time is set to zero, the measurements are executed as fast as possible. The latest measurement can be read out from the device with the command sNuq. The measurements are continued until the stop/clear command (sNc) is issued.



**This command takes the user distance offset and user gain into account**

	Set command	Get command
Command	sNuf+xxxxxxxx<trm>	sNuf<trm>
Return successful	GNuf?<trm>	gNuf+xxxxxxxx<trm>
Return error	gN@Ezzz<trm>	gN@Ezzz<trm>
Parameters	N device Number (DN) xxxxxxxx Sampling time in 10ms (if 0 -> use max. possible sample rate) zzz Error code	

### 9.4.5 Read out – User tracking with buffering (sNuq)

After starting “User-configured tracking with buffering” with the command sNuf, the latest measurement can be read out from the PLDM1010(H) or PLDM1030(H).



**This command takes the user distance offset and user gain into account**

	Command	
Command	sNuq<trm>	
Return successful	gNuq+xxxxxxxx+c<trm>	
Return error	gN@Ezzz+c<trm>	
Parameters	N device Number (DN) xxxxxxxx Distance in 0.1mm c 0 = no new measurement since last sNuq command 1 = one new measurement since last sNuq command, not overwritten 2 = more than one measurement since last sNuq command, overwritten zzz Error code	

## 9.5 Special User configuration commands

### 9.5.1 Set user auto start configuration (sNuA)

This command activates the user stand-alone mode with auto start of the PLDM1010(H) or PLDM1030(H). It triggers continuous measurement of the distance. The distance output at the serial interface (RS-232 and RS-422) is corrected with the user offset and user gain as set with the command 9.5.2 Set/Get user distance offset (sNuof) and 9.5.3 Set/Get user distance gain (sNuga) on page 45. The analog, digital and SSI outputs are updated according to the measured distance values. The sampling time defines the measurement rate. If the sampling time is set to zero, the measurements are executed as fast as possible (depending on target conditions). The user stand-alone mode with auto start is active until the STOP/CLEAR command (sNc) is received by the device.



**The operating mode is stored in the PLDM1010(H) or PLDM1030(H) and activated immediately. This mode is also activated after next power ON.**



**Internally, “tracking with buffering” is started (command sNuF). Therefore, the latest measurement can also be read out from the module with the command sNuq.**

	Command	
Command	sNuA+xxxxxxxx<trm>	
Return successful	gNuA?<trm>	
Return error	gN@Ezzz<trm>	
Parameters	N Device Number (DN) xxxxxxxx Sampling time in 10 ms (if 0 -> max. possible rate) zzz Error code	

### 9.5.2 Set/Get user distance offset (sNuof)

The user can set an individual overall offset correction for all distance measurement commands in this 'Special User Command' section. The standard distances measurement commands are not involved (See 3.5.1 Offset / Gain on page 15).

	Set command	Get command
Command	sNuof+xxxxxxxx<trm>	sNuof<trm>
Return successful	gNoF?<trm>	gNuof+xxxxxxxx<trm>
Return error	gN@Ezzz<trm>	gN@Ezzz<trm>
Parameters	N Device Number (DN) xxxxxxxx Offset in 1/10 mm; + positive / - negative zzz Error code	

Configuration parameters need to be saved (See 9.3.13 Save configuration parameters (sNs) on page 40)

### 9.5.3 Set/Get user distance gain (sNuga)

The user can set an individual user gain to create user defined output values. The output value is calculated as follows (See 3.5.1 Offset / Gain on page 15).

	Set command	Get command
Command	sNuga+xxxxxxxx+yyyyyyyy<trm>	sNuga<trm>
Return successful	gNuga?<trm>	gNuga+xxxxxxxx+yyyyyyyy<trm>
Return error	gN@Ezzz	gN@Ezzz
Parameters	N Device Number (DN) xxxxxxxx GainNum <sub>User</sub> yyyyyyyy GainDen <sub>User</sub> GainDen <sub>User</sub> Must not be zero zzz Error code	

Configuration parameters need to be saved (See 9.3.13 Save configuration parameters (sNs) on page 40)

### 9.5.4 User output protocol (sNu0)

This command modifies the output for the user configured commands. The output can be configured to fit the requirement of an external display.

A parameter for the output mode between 100 and 189 defines the format for an external display. The last digit of the parameter defines the field length for the output number. The output of a distance measurement will be right aligned. The decimal point will be inserted at the position (counted from right) defined by middle digit (See 3.5.2 Output format on page 15).

	Set command	Get command
Command	sNu0+xxxxxxxx<trm>	sNu0
Return successful	gNu0?<trm>	gNu0+xxxxxxxx<trm>
Return error	gN@Ezzz<trm>	gN@Ezzz<trm>
Parameters	<p><i>N</i> Device Number (DN)</p> <p><i>xxxxxxxx</i> Output Mode</p> <p>0: display distance</p> <p>1: display additional information</p> <p>1ab: output formatted for external display</p> <p>a: Number of digits after decimal point</p> <p>b: Field with (sign included) must be greater than 0</p> <p>Conditions: a≤b, if a=b, no decimal point is output.</p> <p><i>zzz</i> Error code</p>	

Configuration parameters need to be saved (See 9.3.13 Save configuration parameters (sNs) on page 40)

## 9.6 Error codes

No.	Format	Meaning and elimination
203	@E203	Wrong syntax in command, prohibited parameter in command entry or non-valid result
210	@E210	Not in tracking mode, start tracking mode first
211	@E211	Sampling too fast, set the sampling time to a larger value
212	@E212	Command cannot be executed, because tracking mode is active, first use command sNc to stop tracking mode
220	@E220	Communication error, check configuration settings
230	@E230	Distance value overflow caused by wrong user configuration. Change user offset (and/or user gain)
231	@E231	Wrong mode for digital input status read, activate DI1
232	@E232	Digital output 1 cannot be set if configured as digital input
233	@E233	Number cannot be displayed. (Check output format)
234	@E234	Distance out of range
236	@E236	Digital output manual mode cannot be activated when configured as digital input
252	@E252	Temperature too high (contact Fotoelektrik-Pauly if error occurs at room temperature)
253	@E253	Temperature too low (contact Fotoelektrik-Pauly if error occurs at room temperature)
254	@E254	Bad signal from target, It takes too long to measure according distance. Use white surface or reflective target.
255	@E255	Received signal too weak or target lost in moving target characteristic (Use different target and distances, if the problem persists, please contact <a href="#">Fotoelektrik-pauly</a> )
256	@E256	Received signal too strong (Use different target and distances, if the problem persists, please contact <a href="#">Fotoelektrik-pauly</a> )
258	@E258	Power supply voltage is too high
259	@E259	Power supply voltage is too low
260	@E260	Distance cannot be calculated because of ambiguous targets. Use clearly defined targets to measure the distance.
263	@E263	Too much light, use only Fotoelektrik-Pauly reflective target plate. In moving target characteristic, distance
264	@E264	Too much light, measuring on reflective targets not possible
330	@E330	Acceleration of the target too strong or distance jump (in moving target characteristic only)
331	@E331	Over speed of target (in moving target characteristic only)
360	@E360	Configured measuring time is too short, set longer time or use 0
361	@E361	Configured measuring time is too long, set shorter time
not listed		Hardware failure (contact Fotoelektrik-Pauly)

Before contacting Fotoelektrik-pauly, please collect as much information as possible.

## 10 Safety instructions

The following instructions are to enable the person responsible for the PLDM1010(H) and PLDM1030(H), and the user of the instrument, to anticipate and avoid operational hazards.

The PLDM1010(H) and PLDM1030(H) is made to be integrated into technical systems. Basic technical training is therefore essential. This device may only be operated by trained personnel.

The person responsible for the instrument must ensure that all users understand these instructions and adhere to them.

If the PLDM1010(H) or PLDM1030(H) is part of a system, the manufacturer of such a system is responsible for all safety-related issues, such as the manual, labeling and instruction.

### 10.1 Use of the instrument

#### Permitted use:

The permitted use of the PLDM1010(H) and PLDM1030(H) is: measuring distances.

#### Prohibited use:

- 1) Use of the instrument without instruction
- 2) Use outside the stated limits
- 3) Deactivation of safety systems and removal of explanatory and hazard labels
- 4) Opening of the equipment, except to open the cover for access to the screw terminal
- 5) Carrying out modification or conversion of the product
- 6) Operation after failure in operation
- 7) Use of accessories from other manufacturers without the express approval of Fotoelektrik-pauly
- 8) Aiming directly into the sun
- 9) Deliberate dazzling of third parties; also in the dark
- 10) Inadequate safeguards at the surveying location (e.g. when measuring on roads, etc.)

**WARNING:** Prohibited use can lead to injury, malfunction, and material damage. It is the duty of the person responsible for the instrument to inform the user about hazards and how to counteract them. PLDM1010(H) or PLDM1030(H) must not be operated until the user has been adequately instructed.

### 10.2 Limits to use

☞ See 5 Technical data on page 21.

#### Environment:

Suitable for use in an atmosphere appropriate for permanent human habitation. The device must not be used in environments such as but not limited to:

- aggressive vapor or liquids (salt, acid, poison, etc.)
- snow and rain
- radiation (radioactive, heat, etc.)
- explosive atmosphere



### 10.3 Areas of responsibility

#### Responsibilities of Fotoelektrik-Pauly:

Fotoelektrik-Pauly is responsible for supplying the product, including the Technical Reference Manual and original accessories, in a completely safe condition.

#### Responsibilities of the manufacturer of non-Fotoelektrik-Pauly accessories:

The manufacturers of non-Fotoelektrik-pauly accessories for the PLDM1010(H) and PLDM1030(H) are responsible for developing, implementing and communicating safety concepts for their products. They are also responsible for the effectiveness of these safety concepts in combination with the Fotoelektrik-Pauly equipment.

#### Responsibilities of the person in charge of the instrument:

**WARNING:** The person responsible for the instrument must ensure that the equipment is used in accordance with the instructions. This person is also accountable for the deployment of personnel and for their training and for the safety of the equipment when in use.

The person in charge of the instrument has the following duties:

- 1) To understand the safety instructions for the product and the instructions in the Technical Reference Manual.
- 2) To be familiar with local safety regulations relating to accident prevention.
- 3) To inform Fotoelektrik-Pauly immediately if the equipment becomes unsafe.

### 10.4 Hazards in use

**WARNING:** The absence of instruction, or the inadequate provision of instruction, can lead to incorrect or prohibited use, and can give rise to accidents with far-reaching personal, material and environmental consequences.

#### Precautions:

All users must follow the safety instructions given by the manufacturer and the directions of the person responsible for the instrument.

**CAUTION:** Beware of erroneous distance measurements if the instrument is defective or if it has been dropped or has been misused or modified.

#### Precautions:

Carry out periodic test measurements, particularly after the instrument has been subject to abnormal use, and before, during and after important measurements. Make sure the PLDM1010(H) or PLDM1030(H) optics are kept clean.

**WARNING:** If labels are hidden when the PLDM1010(H) or PLDM1030(H) is installed, this could lead to dangerous situations.

#### Precautions:

Always ensure the visibility of PLDM1010(H) or PLDM1030(H) labels at all times or add labels in accordance with the local safety regulations.

**CAUTION:** When using the instrument for distance measurements or for positioning moving objects (e.g. cranes, building equipment, platforms, etc.) unforeseen events (e.g. breaking the laser beam) may cause erroneous measurements.

### Precautions:

Only use this product as a measuring sensor, not as a control device. The system must be configured and operated in such a way that no damage will occur in the event of an erroneous measurement, malfunction of the device or power failure due to installed safety measures (e.g. safety limit switch).

**WARNING:** Operate the equipment appropriately in accordance with the regulations in force. Always prevent access to the equipment by unauthorized personnel.

### Precautions:

Do not point the telescope directly at the sun.

**CAUTION:** Be careful when pointing a telescope towards the sun, because the telescope functions as a magnifying glass and can injure eyes and/or cause damage inside the PLDM1010(H) or PLDM1030(H).

## 10.5 Laser classification

The PLDM1010(H) and PLDM1030(H) produces a visible laser beam, which emerges from the front of the instrument. It is a Class 2 laser product in accordance with:

- IEC60825-1 (2007) "Radiation safety of laser products"
- EN60825-1 (2007) "Radiation safety of laser products" It

is a Class II laser product in accordance with:

- FDA 21CFR 1040.10 and 1040.11 (US Department of Health and Human Service, Code of Federal Regulations)

### Laser Class 2/II products:

Do not stare into the laser beam or direct it towards other people unnecessarily. Eye protection is normally afforded by aversion responses including the blink reflex.

**WARNING:** Looking directly into the beam with optical aids (binoculars, telescopes) can be hazardous.

### Precautions:

Do not look into the laser beam. Make sure the laser is aimed above or below eye level. (particularly with fixed installations, in machines, etc.).

**CAUTION:** Looking into the laser beam may be hazardous to the eyes.

## 10.6 Electromagnetic compatibility (EMC)

The term "electromagnetic compatibility" is taken to mean the capability of the PLDM1030(H) to function smoothly in an environment where electromagnetic radiation and electrostatic discharges are present, and without causing electromagnetic interference to other equipment.

**WARNING:** Electromagnetic radiation can cause interference in other equipment. Although the PLDM1030(H) meets the strict regulations and standards that are in force in this respect, Fotoelektrik-Pauly cannot completely exclude the possibility that interference may be caused to other equipment.

## 10.7 Producer Standards

Fotoelektrik-Pauly hereby certifies that the product has been tested and complies with the specifications as stated in this 'Technical Reference Manual'. The test equipment used is in compliance with national and international standards. This is established by our Quality Management System. Further, the PLDM1030(H) devices are produced in compliance with 2002/95/EG «RoHS».

## 10.8 Disposal



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of the equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the dealer where you purchased the product.

In countries in which Fotoelektrik-Pauly has no subsidiaries, Fotoelektrik-Pauly delegates the duty for the disposal in compliance with 2002/96/EG «WEEE» to the local dealer or to the customer, if no dealer is present.

## 10.9 Labeling




Fig. 22a...d: PLDM1010, PLDM1010H, PLDM1030 and PLDM1030H label inclusive type label

## 10.10 Laser Specification

Standard applied	EN60825-1:2007 IEC60825-1:2007
Emitted wavelength	620-690nm
Beam divergence	0.16 x 0.6 mrad
Pulse duration	$0.45 \times 10^{-9}$ s
Max. radiant power	0.95 mW

## 10.11 Maintenance

The PLDM1030(H) is almost maintenance free. The only thing you have to do is to clean the surfaces of the lenses.

**CAUTION:** Look after the surfaces of the lenses with same care that you would apply to spectacles, cameras and field glasses. Clean the optical parts (small laser output glass and the round lens) only with a clean soft glasses cleaning cloth and avoid scratching of the optical parts. All other cleanser or solvent are not allowed.

## 10.12 Service

If you need to service the device, please contact Fotoelektrik-Pauly for instructions.

**CAUTION:** The warranty is void if the device is opened except the cover of the screw terminal. Removing the label is also understood as opening.

D-59368 Werne, 31.03.2017

\* 4901\_\_\*

SRC: E\_49012-2017-03.docx

Fotoelektrik Pauly GmbH & Co. KG

The ownership and design of devices and their electronics are the intellectual property of "Firma Fotoelektrik Pauly GmbH & Co. KG". Internal wiring diagrams can therefore not be provided for copyright reasons. Subject to technical changes and errors. Reproductions or copies of excerpts of this document are only permitted with the approval of "Firma Fotoelektrik Pauly GmbH & Co. KG" and with specification of the source. Infringements shall be liable to prosecution.

